



Fuel gauge

Remaining fuel when only 1st (E) segment starts flashing:
approximately 0.476 US gal (1.80 L)

If the fuel gauge indicator flashes in a repeat pattern or turns off: ➡ P.81



Odometer [TOTAL] & Tripmeter [TRIP A/B]

SEL button switches between the odometer and tripmeters.

- Odometer: Total distance ridden.
- Tripmeter: Distance ridden since tripmeter was reset (press and hold the **SET** button to reset to 0.0 km/mile).