

Changing Air Cleaner Element

Use a new Honda Genuine air cleaner element or an equivalent specified for your motorcycle.

NOTICE

Using the wrong air cleaner element may cause premature engine wear or performance problems.

1. Remove the screw.
2. Remove the right garnish by releasing the prongs from the slots.
 - ▶ The right and left garnish removal can be done in the same way.
3. Remove the left garnish.
4. Remove the air cleaner case cover by removing the screws.

