

Transmission - Change

HONDA

No. Ref.	Old No.	New No.	Description	Reqd. No.
1	C3101416	14101-027-000	Camshaft	1
2	C1001417A	14321-001-010	Gear, cam	1
3	C3101418	14291-027-000	Retainer, cam shaft	1
4	C701601-24	15199-250-000	Knock pin, oil pump cover	1
5	C3101611	15421-027-000	Strainer, oil	1
6	C3102301	23211-027-000	Main shaft, transmission	1
7	C3102302	23221-027-000	Counter shaft, transmission	1
8	C3102307	23421-027-000	Low gear, transmission	1
9	C3102308	23431-027-000	Second gear, transmission	1
10	C3102309	23441-027-000	Top gear, transmission	1
11	CY3102317	23801-027-810	Sprocket, drive 13T	1
	C3102317A	23801-027-010	Sprocket, drive 14T	1
12	C3102318	23110-027-000	Gear comp., primary driven, 65T	1
	CY3102318	23110-027-810	Gear comp., primary driven, 74T	1
13	C1002319	23811-001-000	Plate, drive pocket fixing	1
	CY1102319	23811-011-810	Plate, drive pocket fixing	1
14	C1002324	90601-001-000	Cir clip, 17 mm	1
15	C3102326	90412-027-000	Washer, counter shaft thrust	1
16	C3102327	90481-027-000	Washer, 17.2 mm	1
17	C3102401	24201-027-000	Pawl, gear change	1
18	C3102402	24205-027-000	Shaft, gear change pawl	1
19	C3102444	90023-027-000	Bolt, change stopper pivot	1
20	C3102445A	24208-027-000	Pin, gear shifter	1
21	C3102446	24611-027-000	Shaft, gear shift	1
22	C3102447	24631-027-000	Arm, gear shift	1
23	C3102451	24660-027-000	Stopper comp., gear shift	1
24	C3102452	24672-027-000	Spring, gear shift stopper	1
25	C3102455	24632-027-000	Lever, change	1
26	C3102456	24681-027-000	Holder, change wire	1
27	C3102457	24911-027-000	Collar, 6.5 mm	1
28	C3102459	91302-027-000	O Ring, 8.7×1.8	1
29	C3102460	90602-027-000	Cir clip, 11.8 mm	1
30	C3102501	28801-027-000	Gear A, starter	1
31	C3102502	28805-027-000	Flange, starter	1
32	C3102503	28802-027-000	Gear B, starter	1
33	C3102505	28811-027-000	Shaft, pedal	1
34	C3102508	28820-027-000	Pawl comp., starter	1