

I 14


F-15

Change pedal • Stand • Step

Pédale de changement •
Bequille • Repose pieds

Schaltpedal • Ständer • Tritt

Pedal de cambio • Estante •
Estribo



PEL
•ENS
PIE
•ENS
•RES
•RES
TIGI
•PEDI
•AXE
PRIN
•BARR

SCHALTF
•ARM KOP
EINSCHL
•BREMSSC
•FEDER
•FEDER HI
•BREMSSTA
•BREMSPEC
•ZAPFENWE
•FUSSRAST

Artic

PEDAL, CAME
•ENS. DE BRA
•INCLUSIVE P
•ENS. DE INT
•BAS.
•DATE, PEI
•SORTIF EST.
•QUILLA, FRE
•MP. DE PED
•PIVOTE
•INCIPAL
•PP. DE BARI

Service item	F.R.T.	Ref. No.	Part No.	Description	Reqd. No. CB50 J F	Serial No.	Area code
PEDAL, GEAR CHANGE •ARM ASSY., KICK STARTER INC. RELATIVE PART •SWITCH ASSY., RR. STOP •SPRING, BRAKE PEDAL •SPRING MAIN STAND ROD, RR. BRAKE •PEDAL COMP., BRAKE •SHAFT, MAIN STAND PIVOT •BAR COMP., STEP	0.1	1	24701-149-000	PEDAL, GEAR CHANGE	1 1		
		2	28293-333-000	CLIP, KICK STARTER ARM	1 1		
		3	28300-149-000	ARM ASSY., KICK STARTER	1 1		
		4	28311-342-000	RUBBER, KICK STARTER	1 1		
		5	28333-124-000	SPRING, KICK STARTER STOPPER	1 1		
	0.3	6	35350-149-003	SWITCH ASSY., RR. STOP	1 1		
		7	35357-107-010	SPRING, STOP SWITCH	1 1		
		8	43451-397-000	ROD, RR. BRAKE	1 1		
		9	46500-149-000	PEDAL COMP., BRAKE	1 1		
		10	46514-107-010	SPRING, BRAKE PEDAL	1 1		
		11	50500-149-610	STAND COMP., MAIN	1	1050000 G	
			50500-149-611	STAND COMP., MAIN	1	1051510 B,DK,DM,E	
					1	1050001 G	
					1	1051511 B,DK,DM,E	
					1		AR