

ENGINE SECTION

Chapter Table of Contents

Page Title	Grid	Page
CYLINDER HEAD	1-C1	1-2
R. CRANKCASE COVER	1-C2	1-4
WATERPUMP	1-C3	1-6
CLUTCH	1-C3	1-7
L. CRANKCASE COVER • AC GENERATOR	1-C4	1-8
CRANKCASE	1-C4	1-9
CRANKSHAFT • PISTON	1-C5	1-11
TRANSMISSION	1-C6	1-12
GEARSHIFT DRUM • GEARSHIFT FORK	1-C7	1-14
CARBURETOR	1-C7	1-15