

DESCRIPTION INDEX

Description	Grid	Page	Ref	Description	Grid	Page	Ref
BUSH, PIN	1-D6	2-12	9	COLLAR, DRIVE GEAR	1-C5	1-11	8
	1-D8	2-16	12	COLLAR, FR. AXLE DISTANCE	1-D6	2-13	5
(C)				COLLAR, FR. WHEEL SIDE	1-D6	2-13	3
CABLE ASSY., TACHOMETER	1-D1	2-2	3	COLLAR, L. FR. WHEEL SIDE	1-D6	2-13	4
CABLE, CLUTCH	1-D1	2-3	2	COLLAR, METER	1-D1	2-2	6
CABLE (INNER)	1-D1	2-2	4	COLLAR, PUSH ROD	1-D7	2-14	10
CABLE, THROTTLE	1-D1	2-3	1	COLLAR, RADIATOR SETTING	1-D15	2-30	7
CALIPER SUB-ASSY., R. FR.	1-D6	2-12	16	COLLAR, REARVIEW MIRROR	1-D16	2-32	13
CALIPER SUB-ASSY., RR.	1-D8	2-16	8	COLLAR, RR. AXLE	1-D8	2-17	3
CAP ASSY., NOISE SUPPRESSOR	1-D14	2-28	4	COLLAR, RR. WHEEL DISTANCE	1-D8	2-17	4
CAP, BLEEDER	1-D6	2-12	4	COLLAR, RR. WHEEL SIDE	1-D8	2-17	2
	1-D8	2-16	10	COLLAR, SPRING	1-D5	2-10	3
CAP, CABLE SEALING	1-C7	1-15	12	COLLAR, SWINGARM PIVOT	1-D12	2-25	7
CAP, CARBURETOR	1-C8	1-16	18	CONNECTOR, MASTER CYLINDER	1-D7	2-14	2
CAP, FILLER NECK	1-D15	2-30	4	COUNTERSHAFT, TRANSMISSION	1-C6	1-12	2
CAP, FUEL FILLER	1-D9	2-19	12	COVER, L. CRANKCASE	1-C4	1-8	1
CAP, MASTER CYLINDER	1-D2	2-5	5	COVER, R. CRANKCASE	1-C2	1-4	1
	1-D7	2-14	11	COVER, THERMOSTAT	1-C1	1-2	12
CAP, OIL FILLER	1-C2	1-4	4	COVER, WATER PUMP	1-C3	1-6	3
CAP, RADIATOR FILLER (TOYO)	1-D15	2-30	14	COWL, L. (LOWER)	1-D16	2-32	6
CAP, RESERVE TANK	1-D15	2-30	10	COWL, R. (LOWER)	1-D16	2-32	5
CAP, SWINGARM END	1-D12	2-25	5	COWL, RR.	1-D10	2-21	6
CARBURETOR ASSY. (PF70M)	1-C7	1-15	10	COWL (UPPER)	1-D16	2-32	3
CASE, DRIVE CHAIN	1-D12	2-25	1	CRANKCASE, L.	1-C4	1-9	3
CENTER, CLUTCH	1-C3	1-7	2	CRANKCASE, R.	1-C4	1-9	1
CHAIN, DRIVE (420M-108) (DAIDO)	1-D12	2-25	2	CRANKSHAFT	1-C5	1-11	1
CHAIN, DRIVE (RK420MZ-108RJ)	1-D12	2-25	2	CUP, OIL	1-D7	2-14	5
CHAMBER SET, FLOAT	1-C7	1-15	5	CUP SET, FUEL STRAINER	1-D9	2-19	4
CIRCLIP	1-D2	2-5	15	CUSHION ASSY., RR.	1-D13	2-27	2
CIRCLIP (19MM)	1-C6	1-13	26	CUSHION, RR. FUEL TANK	1-D9	2-19	11
CIRCLIP, MASTER CYLINDER	1-D7	2-14	14	CUSHION, SEAT	1-D10	2-21	4
CIRCLIP (OUTER) (15MM)	1-D11	2-23	9	CYLINDER, A (CODE A)	1-C1	1-2	1
CIRCLIP (OUTER) (17MM)	1-C6	1-13	25	CYLINDER B	1-C1	1-2	1
CLAMP, BRAKE HOSE	1-D12	2-25	6	CYLINDER C	1-C1	1-2	1
CLAMP, CANISTER HOSE	1-C1	1-3	17	CYLINDER HEAD	1-C1	1-2	3
	1-D15	2-31	19	(D)			
CLAMP, FR. BRAKE HOSE	1-D4	2-9	1	DIAPHRAGM	1-D2	2-5	7
CLAMP, MASTER CYLINDER OIL HOSE	1-D7	2-14	7		1-D7	2-14	12
CLAMP, OVERFLOW TUBE	1-C4	1-9	5	DISK, CLUTCH FRICTION	1-C3	1-7	3
CLIP, BAR	1-C7	1-15	11	DISK, FR. BRAKE	1-D6	2-13	8
CLIP, BRAKE HOSE	1-D4	2-8	1	DISK, RR. BRAKE	1-D8	2-17	8
CLIP, BUMPER SETTING	1-D16	2-32	15	DRUM, GEARSHIFT	1-C7	1-14	5
CLIP, CABLE	1-D1	2-2	7	DUST SEAL	1-D5	2-10	9
CLIP, COVER	1-D10	2-21	8	DUST SEAL (20X32X5) (ARAI)	1-D6	2-13	11
CLIP, PISTON PIN (12MM)	1-C5	1-11	5		1-D8	2-17	16
CLIP, TUBE (B18)	1-C8	1-16	22	DUST SEAL (20X32X5) (NOK)	1-D6	2-13	11
CLIP, TUBE (B8)	1-D10	2-20	22		1-D8	2-17	16
CLIP, TUBE (C11)	1-D15	2-31	21	DUST SEAL (31X41)	1-D12	2-25	8
CLIP, TUBE (D12)	1-D15	2-31	20	DUST SEAL, STEERING HEAD	1-D4	2-8	6
CLIP, TUBE (D8)	1-C8	1-16	23	(E)			
CLUTCH OUTER	1-C3	1-7	1	END, HANDLEBAR	1-D3	2-7	3
COIL, IGNITION	1-D14	2-28	3				
COLLAR (17X30.6)	1-C3	1-7	10				