

| Ref. No. | Part No. | Description | Reqd. No. PC50 | No. Used on | | News No. |
|----------|---------------|--|-------------------|--------------|-------|----------|
| | | | | From | To | |
| 1 | 11331-063-020 | COVER, right crankcase | 1 | PC50-1000001 | | |
| 2 | 11332-063-000 | LABEL, oil | 1 | PC50-1000001 | | |
| 3 | 11394-063-010 | PACKING, right crankcase cover..... | 1 | PC50-1000001 | | |
| 4 | 24615-044-010 | GUIDE, free pole | 1 | PC50-1000001 | | |
| 5 | 24612-063-000 | CAP, free pawl slider | 1 | PC50-1000001 | | |
| 6 | 24611-063-700 | SLIDER, free pawl..... | 1 | PC50-1000001 | | |
| 7 | 91212-063-005 | OIL-SEAL, 5.30.6 (Nihon Oil-Seal)..... | 1 | PC50-1000001 | | |
| 8 | 90456-063-000 | WASHER, 5x30..... | 1 | PC50-1000001 | | |
| 9 | 15650-063-000 | GAUGE, oil | 1 | PC50-1000001 | | |
| 10 | 91311-044-000 | O-RING, 18x3 | 1 | PC50-1000001 | | |
| 11 | 28252-064-000 | CAP, kick spindle hole..... | 1 | PC50-1000001 | | |
| 12 | 91204-063-003 | OIL-SEAL, 16.26.6 (Arai) | 1 | PC50-1000001 | | |
| 13 | 93500-06025 | SCREW, pan, 6x25 | 4 | | | |
| 14 | 93500-06032 | SCREW, pan, 6x32 | 1 | | | |
| 15 | 93500-06090 | SCREW, pan, 6x90 | 2 | | | |
| 16 | 93500-06100 | SCREW, pan, 6x100..... | 1 | | | |