

F-20 Change pedal · Kick arm

Ref. No.	Part No.	Description	Reqd. No. SS50Z K1 K3	Serial No.	Area code
1	24700-041-731	PEDAL, GEAR CHANGE	1		E, F, H
	24701-150-000	PEDAL, GEAR CHANGE	1		F, H
2	24700-098-670	PEDAL, GEAR CHANGE	1		B
	24701-051-691	PEDAL, GEAR CHANGE	1		B
3	24781-205-000	RUBBER, GEAR CHANGE PEDAL 95011-40000	1		B, F, H
	95011-40000	RUBBER, CHANGE PEDAL	1 1		
4	28300-051-830	ARM ASSY., KICK STARTER	1 1		E, F, H
5	28300-061-000	ARM ASSY., KICK STARTER	1 1		B
6	28301-040-000	ARM, KICK STARTER	1 1		B
7	28302-056-000	PEDAL, KICK STARTER	1 1		B
8	28303-001-000	WASHER, KICK STARTER KNUCKLE	1 1		B
9	28322-001-000	SPRING, KICK STARTER KNUCKLE	1 1		B
10	28324-001-000	CLIP, KICK STARTER KNUCKLE	1 1		B
11	92000-06020	BOLT, HEX., 6X20	2 2		
12	95011-51000	RUBBER A, KICK STARTER	1 1		