

SELECTION TABLES • MANUALS

Selection table of connecting rod big end bearing
(Radial clearance 7~19 μm) (Block No. E-10)

Connecting rod I.D. 24φ		Crank pin O.D. 18φ	-0.001~ -0.005	
		B or Blue	+0.010~ +0.006	Red 91001-GWC-008
		C or White	+0.006~ +0.002	Blue 91002-GWO-008
		D or Green	+0.002~ -0.002	White 91003-GWO-008
		E or Yellow	-0.002~ -0.006	Green 91004-GWO-008

Selection table for lock or blank key
Refer to the following selection table to select the lock or blank key. (Block No. F-22)

Type	Key No.
TYPE 1	A** . B**
TYPE 2	C** . D**

* : 0, 1, 2, 3, 4, 5, 6, 7, 8 or 9

DESCRIPTION	QTY. REQ.	MANUAL NUMBER	H/C
EZ90 '91 Owner's manual	1	31GZ4600	3221306
EZ90 '91 Service manual	1	61GZ490	3221314