



E-2 Contact Breaker • Spark Advancer



E-2 Contact Breaker • Spark Advancer



Ref. No.	Part No.	Description	Reqd. No. CBI25S1	Serial No.	Area Code
1	12332-324-000	BASE, CONTACT BREAKER	1		
2	30200-107-014	BREAKER ASSY., CONTACT (ND)	1		
	30200-107-154	BREAKER ASSY., CONTACT (TOYO)	1		
3	30201-107-004	PLATE, CONTACT BREAKER BASE (ND)	1		
	30201-107-154	PLATE, CONTACT BREAKER BASE (TOYO)	1		
4	30202-107-004	BREAKER, CONTACT (ND)	1		
	30202-107-154	BREAKER, CONTACT (TOYO)	1		
5	30205-028-004	FELT, OIL (ND)	1		
	30205-306-154	FELT, OIL (TOYO)	1		
6	30220-107-004	ADVANCER ASSY., SPARK (ND)	1		
	30220-107-154	ADVANCER ASSY., SPARK (TOYO)	1		
7	30370-324-000	COVER, CONTACT BREAKER	1		
8	30372-107-000	GASKET, CONTACT BREAKER COVER	1		
9	90482-028-000	WASHER, 5MM	2		
10	90486-028-000	WASHER, SPARK ADVANCER SETTING	1		
11	91202-107-003	OIL SEAL, 15X25X7	1		
12	91301-107-000	O-RING, 75X2.5	1		
13	92000-06014	BOLT, HEX., 6X14	1		
14	93500-05012-0A	SCREW, PAN, 5X12	2		
15	93500-06025	SCREW, PAN, 6X25	2		
16	93700-05022-0B	SCREW, OVAL, 5X22	2		
17	94101-04000	WASHER, PLAIN, 4MM	2		
18	94111-04000	WASHER, SPRING, 4MM	2		
19	99500-04007-0A	SCREW, HOLLOW PAN, 4X7	2		

B110-2