


E-16

TRANSMISSION

G 8



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
+30		.INCLUDES: Engine removal and installation .NOTE: PGM-FI type	
31	2101C7	BEARING, COUNTERSHAFT :LEFT --	4.7
	2101M4	BEARING, COUNTERSHAFT(A) :LEFT .INCLUDES: Engine removal and installation	4.9
32	2101C2	BEARING, MAINSHAFT :LEFT -----	4.7
	2101M3	BEARING, MAINSHAFT(A) :LEFT -- .INCLUDES: Engine removal and installation	4.9
	2101C6	BEARING, MAINSHAFT :BOTH -----	4.9
	2101L9	BEARING, MAINSHAFT(A) :BOTH -- .INCLUDES: Engine removal and installation	5.1
+33	2101C8	BEARING, COUNTERSHAFT :RIGHT -	4.7

Ref. No.	Part No.	Description	Reqd. QTY							Serial No.	Parts catalogue code
			4	5	6	7	8	9	A		
19	90441-KW7-930	PLATE, BEARING HOLDER -----	1	1	1	1	1	1	1		
20	90452-KGH-900	WASHER, SPECIAL, 12MM -----	1	1	1	1	1	1	1		
21	90454-107-000	WASHER, THRUST, 20MM -----	2	2	2	2	2	2	2		
22	90461-115-000	WASHER, SPLINE, 17MM -----	2	2	2	-	2	-	-		
	90461-KK6-000	-----	-	-	-	-	-	-	-		
23	90463-437-000	WASHER, SPLINE, 22MM -----	2	2	2	2	2	2	2		
24	90464-444-000	WASHER, SPLINE, 22MM -----	1	1	1	1	1	1	1		
25	90465-KE1-010	WASHER, LOCK -----	1	1	1	1	1	1	1		
26	90601-001-000	CIRCLIP, EXTERNAL, 17MM -----	2	2	2	2	2	2	2		
27	90601-437-000	CIRCLIP, EXTERNAL, 22MM -----	2	2	2	2	2	2	2		
28	91216-KGH-901	OIL SEAL, 20X34X7 -----	1	1	1	1	1	1	1		
29	95701-06014-00	BOLT, FLANGE, 6X14 -----	2	2	2	2	2	2	2		
30	96100-62030-00	BEARING, RADIAL BALL, 6203 --	1	1	1	1	1	1	1		
31	96100-62040-00	BEARING, RADIAL BALL, 6204 --	1	1	1	1	1	1	1		
32	96140-62010-00	BEARING, RADIAL BALL, 6201U -	1	1	1	1	1	1	1		
33	96140-62020-00	BEARING, RADIAL BALL, 6202U -	1	1	1	1	1	1	1		
34	23502-KTY-D30	BUSH, 20MM -----	-	-	-	-	-	-	-		
35	23522-KTY-D30	COLLAR, SPLINE, 20MM -----	-	-	-	-	-	-	-		
36	90401-KTY-D30	WASHER, THRUST, 17MM -----	-	-	-	1	-	1	1		