



FRAME GROUP

Ref. No. 56 ~ 85

Block No.	Ref. No.	Part No.	Description	Reqd. No. CR125M1	Serial No.	Area Code
2A	56	43151-110-000	SPRING, BRAKE SHOE	4		
2C	57	43410-361-670	ARM, REAR BRAKE	1		
2C	58	43431-360-000	ARM, REAR BRAKE STOPPER	1		
2C	59	43434-286-000	RUBBER, STOPPER ARM CUSHION	2		
2B	60	43450-361-000	CABLE COMP., REAR BRAKE	1		
2A	61	44301-110-000	AXLE, FRONT WHEEL	1		
2A	62	44311-360-000	COLLAR, FRONT WHEEL SIDE	1		
2A	63	44601-360-000	HUB, FRONT WHEEL	1		
2A	64	44606-360-305	SPOKE A ASSY., FRONT	18		
2A	65	44607-360-305	SPOKE B, FRONT	18		
2A	66	44620-030-000	COLLAR, FRONT AXLE DISTANCE	1		
2A	67	44701-355-000	RIM, FRONT WHEEL	1		
2A	68	44711-360-003	TIRE, FRONT WHEEL (2.75-21) (BS)	1		
2A	69	44712-329-003	TUBE, FRONT WHEEL (2.75-21) (BS)	1	2015067	
		44712-360-003	TUBE, FRONT WHEEL (2.75/3.00-21 BS)	1	2015068	
2A	70	44713-329-003	FLAP, TIRE (BS)	1		
2A	71	44715-355-000	STOPPER, FRONT WHEEL TIRE BEAD 1.40	1	2017920	
		44715-355-006	STOPPER, BEAD, 1.40 (NITTO)	1	2017921	
2A	72	44835-365-670	CAP, GEAR BOX HOLE	1		
2A	73	45100-360-700	PANEL COMP., FRONT BRAKE	1		
2A	74	45131-365-670	CAM, FRONT BRAKE	1		
2A	75	45134-121-000	SEAL, DUST	1		
2C	76	45134-250-000	SEAL, BRAKE CAM DASH	1		
2A	77	45145-365-670	INDICATOR, FRONT BRAKE	1		
2A	78	45410-365-670	ARM, FRONT BRAKE	1		
1B	79	45450-361-000	CABLE COMP., FRONT BRAKE	1	2001415	
		45450-360-000	CABLE COMP., FRONT BRAKE	1	2001415	
2A	80	45454-360-010	SPRING, FRONT BRAKE CABLE	1		
2A	81	45465-329-010	CLIP, FRONT BRAKE CABLE	1		
1A	82	45466-329-000	INNER, CABLE GUIDE	1		
1A	83	45468-360-000	CLIP B, FRONT BRAKE CABLE	1		
2B	84	46500-360-000	PEDAL, BRAKE	1		
2B	85	46513-357-010	SHAFT, BRAKE PIVOT	1		

Ref. No. 86 ~ 120

FRAME GROUP

Block No.	Ref. No.	Part No.	Description	Reqd. No. CR125M1	Serial No.	Area Code
2B	86	46514-360-000	SPRING, REAR BRAKE RETURN	1		
2B	87	46516-357-000	SEAL, BRAKE PEDAL DUST	2		
2B	88	50100-360-700B	BODY COMP., FRAME	1		
1A	89	50301-041-305	RACE, STEERING TOP BALL	2		
2B	90	50351-360-000	PLATE, RIGHT ENGINE HANGER	1		
2B	91	50352-360-000	PLATE, LEFT ENGINE HANGER	1		
2B	92	50500-360-810	STAND, CENTER	(11)		
2B	93	50530-360-000	BAR, SIDE STAND	1		
2B	94	50542-310-010	SPRING, SIDE STAND	1		
2B	95	50603-056-000	PIN, STEP BAR JOINT	2		
2B	96	50616-357-000	STEP COMP., RIGHT	1		
2B	97	50617-329-000	SPRING, RIGHT STEP RETURN	1		
2B	98	50642-357-000	STEP COMP., LEFT	1		
2B	99	50644-329-000	SPRING, LEFT STEP RETURN	1		
1A	100	51400-360-700	FORK ASSY., RIGHT FRONT 51400-360-701	1		
		51400-360-701	FORK ASSY., RIGHT FRONT	1		
1B	101	51401-360-000	SPRING, FRONT CUSHION	2		
1B	102	51410-360-701	PIPE, FRONT FORK	2		
2A	103	51412-331-770	SPRING, FRONT CUSHION REBOUND	2		
2A	104	51421-360-010	CASE, RIGHT FRONT FORK BOTTOM	1		
2B	105	51425-110-003	SEAL, FRONT FORK DUST	2		
2B	106	51432-360-000	PIECE, OIL LOCK	2		
2B	107	51437-331-770	RING, PISTON	2		
2A	108	51440-360-000	SEAT COMP., UPPER	2		
1B	109	51449-355-003	CAP, FORK PIPE 51449-355-013	2		
		51449-355-013	CAP, FORK PIPE	1		
1B	110	51454-355-013	SEAT, UPPER SPRING 51460-355-305	2		
		51460-355-305	SEAT SET, UPPER SPRING	2		
1A	111	51500-360-700	FORK ASSY., LEFT FRONT 51500-360-701	1		
		51500-360-701	FORK ASSY., LEFT FRONT	1		
2A	112	51521-360-010	CASE, LEFT FRONT FORK BOTTOM	1		
2C	113	52109-360-300	BUSH, PIVOT THRUST	2		
2C	114	52110-360-700B	FORK COMP., REAR	1		
2C	115	52141-360-010	COLLAR, REAR FORK CENTER	1		
2C	116	52144-360-003	CAP, REAR FORK DUST SEAL	2		
2C	117	52156-310-700	GUIDE, CHAIN	1		
2C	118	52170-360-000	SLIDER, CHAIN	1		
2C	119	52400-360-700	CUSHION ASSY., REAR	2		
2C	120	52401-360-000	SPRING A, REAR CUSHION	1		
		52401-360-810	SPRING A, REAR CUSHION	1		
		52401-360-820	SPRING A, REAR CUSHION	1		