

1	BASE	11321-201-020
2	GASKET	11392-200-000
3	PLATE, POINT BASE	30200-003-004
3	PLATE, POINT BASE	30200-039-005
3	PLATE, POINTS BASE	30200-039-154
4	PLATE, POINTS BASE	30201-003-004
4	PLATE, POINTS	30201-205-014
5	POINTS	30202-253-014
6	FELT, OIL	30205-205-014
7	CONDENSER	30250-205-034
7	CONDENSER	30251-003-004
8	COIL, IGNITION	30500-202-004
8	COIL, IGNITION	30500-230-000
9	ALTERNATOR ASSY.	31100-205-094
9	RUBBER (26MM)	90802-200-000
10	ROTOR	31102-205-094
11	STATOR ASSY.	31103-205-094
12	BOLT	31104-201-004
13	WASHER	31105-200-000
14	GROMMET	32971-200-000
15	GROMMET, WIRE	32971-205-000
16	OIL SEAL (17.9X38X5)	91305-202-010
17	BOLT, HEX. (6X30)	92000-06030
17	BOLT, HEX. (6X30)	92101-06030-0A
18	BOLT, STUD (6X40)	92700-06040
18	BOLT, STUD (6X40)	92700-06040-0B
18	BOLT, STUD (6X28)	92900-06028-0B
18	BOLT, STUD (6X28)	92900-06028-08
19	SCREW, PAN (5X12)	93500-05012
19	SCREW, PAN (5X12)	93500-05012-0A
20	SCREW, PAN (6X22)	93500-06022
20	SCREW, PAN (6X22)	93500-06022-0A
21	SCREW, PAN (6X50)	93500-06050
21	SCREW, PAN (6X50)	93500-06050-0A
22	NUT, HEX. (6MM)	90310-KA3-711
22	NUT, HEX. (6MM)	94000-06000-0S
22	NUT, HEX. (6MM)	94001-06000
22	NUT, HEX. (6MM)	94001-06000-0S
22	NUT, HEX. (6MM)	94001-06008-0S
22	NUT, HEX. (6MM)	94001-06200-0S
22	NUT, HEX. (6MM)	94030-06000
23	WASHER, PLAIN (5MM)	94101-05000
24	WASHER, SPRING (6MM)	94111-06000

