


# E - 14

## Transmission



Bagian yang diservice	F.R.T.	Nomor Petunjuk	Nomor Part	Uraian Part	Jumlah	Nomor Serie	Catatan
MAINSHAFT, TRANSMISSION.....	4.5	26	90464-360-000	WASHER, COUNTERSHAFT THIRD SPLINE	1		
.Replace countershaft add .....	0.2	27	90465-360-000	WASHER, LOCK	1		
COUNTERSHAFT, TRANSMISSION ....	4.5	28	90601-437-000	CIRCLIP, EXTERNAL, 22MM	2		
.Replace mainshaft add.....	0.2	29	90605-200-000	SET RING, 20MM	2		
SPROCKET, DRIVE .....	0.2	30	91005-KCN-003	BEARING, RADIAL BALL, 20X55X11	1		
BEARING, MAINSHAFT :RIGHT .....	4.5						
BEARING, MAINSHAFT :BOTH.....	4.7	31	91015-KK6-003	BEARING, RADIAL BALL, 6202U	1		
BEARING, MAINSHAFT AND		32	91201-KCS-920	OIL SEAL, 20X34X7	1		
COUNTERSHAFT :ALL.....	4.9	33	92101-06010-0A	BOLT, HEX., 6X10	2		
BEARING, MAINSHAFT :LEFT .....	4.5	34	96100-62040-00	BEARING, RADIAL BALL, 6204	1		
BEARING, COUNTERSHAFT :LEFT ....	4.5	35	96600-06016-08	BOLT, SOCKET, 6X16	1		