

ILLUSTRATION MANAGEMENT NUMBER (IDENTIFICATION)
FOR '06 COTA 4RT PARTS LIST

ENGINE GROUP	ILLUSTRATION NUMBER	FRAME GROUP	ILLUSTRATION NUMBER
E-1	Cylinder head.....	F-1	Cable - Switch.....
E-2	Camshaft - Valve.....	F-2	Front brake master cylinder.....
E-3	Camchain - Tensioner.....	F-3	Clutch master cylinder.....
E-4	Cylinder.....	F-4	Steering handle pipe - Top bridge.....
E-5	R. Crankcase cover.....	F-5	Steering stem.....
E-6	Clutch.....	F-6	Front fender.....
E-7	Oil pump.....	F-7	Front fork.....
E-8	Water pump.....	F-8	Front brake caliper.....
E-9	L. Crankcase cover.....	F-9	Front wheel.....
E-10	Generator.....	F-10	Rear brake caliper.....
E-11	Crankcase.....	F-11	Rear brake master cylinder.....
E-12	Crankshaft - Piston.....	F-12	Rear wheel.....
E-13	Transmission.....	F-13	Fuel tank - Fuel pump.....
E-14	Gearshift drum.....	F-14	Rear fender.....
E-15	Kick starter spindle.....	F-15	Air cleaner.....
E-16	Throttle body - Injector.....	F-16	Exhaust muffler.....
		F-17	Pedal - Kick starter arm.....
		F-18	Stand - Step.....
		F-19	Swingarm.....
		F-20	Rear cushion.....
		F-21	Wire harness.....
		F-22	Radiator.....
		F-23	Frame body.....
		F-24	Emblem - Stripe.....