

E-8 Crankcase

C 10

E-8 Crankcase

Ref. No.	Part No.	Description	Reqd. No. CR250M	Serial No.	Area Code
1	11000-357-000	CRANKCASE SET	1	1000224	
	11000-357-010	CRANKCASE SET	1	1000225	
2	11105-357-010	PLATE, BEARING SET	1		
3	11107-357-303	COLLAR, DRUM STOPPER SPRING	1		
4	11108-357-000	PLATE, BEARING SIDE	1		
5	11109-357-303	COLLAR, SHIFT RETURN SPRING	1		
6	11191-357-030	GASKET, CRANKCASE	1		
7	23216-357-000	PLATE, BEARING STOPPER	1		
8	24652-357-000	PIN, SHIFT RETURN SPRING	1		
9	28254-357-000	PIN, KICK STOPPER	1		
10	90031-357-010	STUD, CYLINDER, 8X126.5	4		
11	91004-357-000	BEARING, RADIAL BALL, 17X42X12	1	1005555	
	91004-357-010	BEARING, RADIAL BALL, 17X42X12	1	1005556	
12	91005-357-000	BEARING, RADIAL BALL, 6304	1	1005555	
	91005-357-010	BEARING, RADIAL BALL, 6304	1	1005556	
13	91006-357-000	BEARING, RADIAL BALL, 6205Z	1	1005555	
	91006-357-010	BEARING, RADIAL BALL, 6205Z	1	1005556	
14	91007-357-000	BEARING, RADIAL BALL, 6203Z	1	1005555	
	91007-357-010	BEARING, RADIAL BALL, 6203Z	1	1005556	
15	91031-329-000	BEARING, NEEDLE, 16X4	1		
16	91202-357-003	OIL SEAL, 25X55X10	1		
17	91203-357-003	OIL SEAL, 38X64X13.5	1		
18	91206-286-013	OIL SEAL, 14X28X7	1		
19	91206-329-000	OIL SEAL, 16X22X3.5	1		
20	91207-357-000	OIL SEAL, 20X34X7	1		
21	92800-12000	BOLT, DRAIN PLUG, 12MM	1		
22	93500-06035	SCREW, PAN, 6X35	4		
23	93500-06045	SCREW, PAN, 6X45	1		
24	93500-06060	SCREW, PAN, 6X60	8		
25	93500-06070	SCREW, PAN, 6X70	1		
26	93600-06014	SCREW, FLAT, 6X14	6		
27	94109-12000	WASHER, DRAIN PLUG, 12MM	1		
28	94301-10160	PIN A, DOWEL, 10X16	2		
29	95001-55300-40	TUBE, FUEL, 5.3X300	1	1010224	
	95001-55260-40	TUBE, FUEL, 5.3X260	1	1010225	
30	95002-02100	CLIP B10, TUBE	1		
31	96102-63063-00	BEARING, RADIAL BALL, 6305	2		

