
The starter motor turns when the transmission is in neutral, but does not turn with the transmission in any position except neutral, with the side stand up and the clutch lever pulled in.



## Starter Motor Turns Slowly

- Low specific gravity in battery (or dead battery)
- · Poorly connected battery terminal cable
- Poorly connected starter motor cable
- Faulty starter motor
- Poorly connected battery ground cable

## Starter Motor Turns, But Engine Does Not Turn

- Starter motor is running backwards
  - Case assembled improperly
  - Terminals connected improperly
- · Faulty starter clutch
- · Damaged or faulty starter pinion
- Damaged pinion gears

## Starter Relay Switch "Clicks", But Engine Does Not Turn Over

- Crankshaft does not turn due to engine problems
- Excessive pinion gear friction