


Meter Removal/Installation



Requisite service

- Headlight removal/installation (page 16-3)

Procedure		Qty	Remarks
Removal Order			Installation is in the reverse order of removal. Connection (page 1-21)
(1)	Meter connector	2	
(2)	Speedometer cable	1	
(3)	Speedometer mounting bolt	2	
(4)	Speedometer assembly	1	