

Tools

- The tools for bearing removal and installation are not contained in this list. Refer to section 1, Ball Bearing Replacement, of the Common Service Manual.
- The newly designed tools are indicated with * mark in the list.

Description	Tool number	Remarks	Ref. sect(s)
Vacuum gauge	07404-0030000	or M937B-021-XXXX (U.S.A. only)	3
Drive chain cutter	07HMH-MR10102	Drive chain (After '93)	3
-Link plate holder	07NMH-MW00110 or		
	07PMH-MZ20110		
Pilot screw wrench		Carburetor	3
'90-'93:	07908-4730002		
After '93: (Canada type)	07908-4220201		
(49 state/California)	07KMA-MS60101 and		
	07PMA-MZ20110		
Oil filter wrench	07HAA-PJ70100	Oil filter	4
Oil pressure gauge	07506-3000000	or equivalent commercially available in	4
Oil pressure gauge attachment	07510-4220100	U.S.A.	4
Antifreeze tester	Commercially available		5
Cooling system tester	Commercially available		5
Float level gauge	07401-0010000	Carburetor	6
Lock nut wrench	07HMA-MR70200	Engine mount	7
*Pivot lock nut wrench	07908-4690002	Swingarm	7, 13
Valve guide driver	07HMD-ML00100	Valve guide	8
Tappet hole protector	07HMG-MR70001	Valve	8
Valve spring compressor	07757-0010000		8
Valve spring compressor attachment	07959-KM30101		8
Valve seat cutter, 24.5 mm (45° EX)	07780-0010100	or equivalent commercially available in	8
Valve seat cutter, 29 mm (45° IN)	07780-0010300	U.S.A.	8
Valve flat cutter, 25 mm (32° EX)	07780-0012000		8
Valve flat cutter, 30 mm (32° IN)	07780-0012200		8
Valve interior cutter, 30 mm (60° IN)	07780-0014000		8
Valve interior cutter, 26 mm (60° EX)	07780-0014500		8
Cutter holder, 4.5 mm	07781-0010600		8
Valve guide reamer, 4.5 mm	07HMH-ML00101	or equivalent commercially available in	8
Compression gauge	07305-0010000	U.S.A.	8
Compression gauge attachment	07JMJ-KY20100 or		8
	07PMJ-MY50100		
Clutch center holder	07724-0050001	Clutch	9
Lock nut wrench 26 x 30 mm	07716-0020203		9
Driver	07746-0030100	Mainshaft bearing	11
Attachment, 25 mm I.D.	07746-0030200		11
Bearing remover head, 20 mm	07746-0050600	Front wheel bearing	12
Bearing remover shaft	07746-0050100		12
Driver	07749-0010000		
Attachment, 42x 47 mm	07746-0010300	Front wheel bearing	12, 13
		Rear axle housing	
		Driven sprocket hub	
Pilot, 20 mm	07746-0040500	Front wheel bearing	12, 13
Fork seal driver	07947-KA50100	Fork	12
Fork seal driver attachment	07947-KF00100		12
Lock nut wrench, 30 x 32 mm	07716-0020400	Steering	12
Steering stem socket	07916-3710100		12
Ball race remover set	07946-KM90001	Steering head	12
- Driver attachment A	07946-KM90100	Included in set	
- Driver attachment B	07946-KM90200		
- Driver shaft assembly	07946-KM90300		
- Bearing remover A	07946-KM90401		
- Bearing remover B	07946-KM90500		
- Base assembly	07946-KM90600		
Steering stem driver	07946-MB00000		