

⚠ WARNING

- Do not service the exhaust system while it is hot.

NOTE

- Replace the exhaust pipe gaskets if the exhaust system is removed.

Requisite Service

- Support the motorcycle using a hoist.
- Remove the rear wheel (page 13-2).

Procedure	Q'ty	Remarks
Removal Order		• Installation is in the reverse order of removal.
(1) Lower cover bolt	3	
(2) Lower cover	1	
(3) Bolt	4	
(4) Footpeg bracket bolt	2	
(5) Footpeg bracket	1	
(6) Front exhaust joint nut	4	
(7) Exhaust pipe band bolt	2	Not necessary to remove, just loose.
(8) Front exhaust pipe	1	
(9) Gasket	2	
(10) Muffler protector	1	
(11) Exhaust chamber joint nut	3	
(12) Exhaust chamber	1	
(13) Gasket	2	
(14) Rear exhaust pipe joint nut	4	
(15) Rear exhaust pipe	1	
(16) Gasket	2	
Installation order		
(16) Gasket	2	
(15) Rear exhaust pipe	1	
(14) Rear exhaust pipe joint nut	4	Tighten to the specified torque.
(13) Gasket	2	
(12) Exhaust chamber	1	
(11) Exhaust chamber joint nut	3	Install but do not tighten yet.
(10) Muffler protector	1	
(9) Gasket	2	
(8) Front exhaust pipe	1	
(7) Exhaust pipe band bolt	2	Install but do not tighten yet.
(6) Front exhaust joint nut	4	After installing, tighten the following in sequence.
		①Exhaust pipe band bolt (7)
		②Exhaust chamber joint nut (11)
		③Front exhaust joint nut (6)
(5) Footpeg bracket	1	
(4) Footpeg bracket bolt	2	
(3) Bolt	4	
(2) Lower cover	1	
(1) Lower cover bolt	3	