

Requisite Service

- Combination meter removal/installation (page 18-10)

Procedure		Q'ty	Remarks
Disassembly Order			Assembly is in the reverse order of disassembly.
(1)	Screw/collar	2/2	At installation, align the holes with the clock adjusting buttons on the meter lens securely.
(2)	Cover	1	
(3)	Screw	1	
(4)	Reset knob	1	
(5)	Screw	5	
(6)	Visor	1	
(7)	Lens	1	
(8)	Plate	1	
(9)	Screw	3	
(10)	Speedometer	1	
(11)	Screw	4	
(12)	Tachometer	1	
(13)	Screw	6	
(14)	Fuel/temperature gauge	1	
(15)	Screw	5	
(16)	Clock unit	1	
(17)	Screw	3	
(18)	Indicator check unit	1	

