


REAR SHOCK ABSORBER

The rear shock absorber (1) have five adjustment positions for different load or riding conditions. Position II is standard.

Position I is for light loads and smooth road conditions. Positions III to V increase spring preload for a suspension, and can be used when the TRX is heavily loaded. Select the position best suited to your rear load and riding condition.

NOTE: The shock absorbers should be adjusted equally on both sides.

Adjustment Position	Rear Load
III	0 ~ 20 kg (0 ~ 44 lbs)
IV	20 ~ 40 kg (44 ~ 88 lbs)
V	40 ~ 60 kg (88 ~ 133 lbs)



(1) Rear shock absorber