

Quick Reference

Initial Maintenance	about 100 miles (150 km) or 1 month.
Regular Maintenance	about every 600 miles (1,000 km) or 6 months.
Pre-ride Inspection	Check the following items each time before you ride (page 26): tires, spokes & rims, leaks, engine oil, fuel, drive chain, cables, nuts & bolts, spark plug & cap, throttle, brakes, and clutch lever.
Fuel/Capacity	unleaded gasoline, pump octane number of 86 or higher tank: 0.98 US gal (3.7 ℓ)
Engine Oil/Capacity	API Service Classification SG or higher except oils labeled as energy conserving or resource conserving on the circular API service label, SAE 10W-30, JASO T 903 standard MA, Pro Honda GN4 4-stroke oil (USA & Canada), or Honda 4-stroke oil, or an equivalent motorcycle oil after draining: 0.9 US qt (0.85 ℓ)
Maximum Weight Capacity	CRF125F: 176 lb (80 kg) CRF125FB: 194 lb (88 kg) rider only (no passenger or cargo) and any accessories
Tires	Front: CRF125F: 70/100–17M/C 40M CRF125FB: 70/100–19M/C 42M Rear: CRF125F: 90/100–14M/C 49M CRF125FB: 90/100–16M/C 51M Type: bias-ply, tube
Tire Pressure (cold)	Front: 15 psi (100 kPa , 1.0 kgf/cm ²) Rear: 15 psi (100 kPa , 1.0 kgf/cm ²)
Spark Plug	CPR6EA-9 (NGK)
Fuse	main: 15 A sub: 5 A