


Carburetor Adjustment

1. Start and warm up the engine to normal operating temperature.
2. Set the engine idle speed to $1,200 \text{ min}^{-1}$ (1,200 rpm) [250N type: $1,300 \text{ min}^{-1}$ (1,300 rpm)] by adjusting the stop screw (1). Turning the stop screw in the (A) direction will increase the rpm, and turning in the (B) direction will result in a decrease.



Ajuste del carburador

1. Arranque y caliente el motor hasta llegar a la temperatura normal de funcionamiento.
2. Ajuste la velocidad del motor de marcha en vacío a $1,200 \text{ min}^{-1}$ (1,200 r.p.m.) [tipo 250N: $1,300 \text{ min}^{-1}$ (1,300 r.p.m.)], mediante el tornillo de detención (1). Girando el tornillo de detención en la dirección (A) aumentarán las r.p.m., y girándolo en la dirección (B) reducirán.