

Tire Pressure—Check pressure and inflate to recommended pressure if incorrect.

WARNING

* **Correct air pressure will provide maximum stability, riding comfort and tire life.**

Be sure to follow the tire specification below:

Cold tire pressures kg/cm ² (psi)	Front: 1.5 (21) Rear: 2.0 (28)
Vehicle capacity load limit	82 kg (180 lbs)
Tire size	Front: 2.25-14 (4PR) Rear: 2.25-14 (4PR)

* **Check tire pressures frequently and adjust if necessary.**

* **Operation with excessively worn tires is very hazardous and will adversely affect traction, steering and handling.**

* **Improper tire inflation will cause abnormal tread wear or other damage and create a safety hazard. Riding with under-inflated tires will cause the tires to slip on the rims damaging the inner tube valves. Severe underinflation may result in loss of the tire from the rim.**