

## LOADING AND ACCESSORIES

### **▲ WARNING**

- \* **A motorcycle is sensitive to changes in weight distribution. Improper loading of cargo can impair the motorcycle's stability and performance. To prevent an accident, use extreme care when riding with cargo. These general guidelines may help you decide whether or how to equip your motorcycle, and how to load it safely.**

### **Loading**

The combined weight of the rider, passenger and cargo must not exceed the maximum weight capacity:

185 kg (407 lbs)

1. Keep cargo weight low and close to the center of the motorcycle. Load weight equally on both sides to minimize imbalance. As weight is located further from the motorcycle's center of gravity, handling is proportionally affected.
2. All cargo must be secure for stable handling. Recheck cargo security frequently.