

CROSSING SLOPES

To maintain balance and stability when riding across a slope, you need to *shift weight toward the uphill side of the vehicle*. To do this, move your body off the center of the seat and lean toward the uphill side. On a slippery or loose surface, you may also need to steer slightly uphill to maintain a straight course across the slope. Avoid crossing hills that are excessively steep, slippery or rough.




Fig. 3-16

Shift weight uphill when crossing slopes.