

Keeping your CRF well maintained is absolutely essential to your safety. It's also a good way to protect your investment, get maximum performance, avoid breakdowns, and have more fun.

To help keep your CRF in good shape, this section includes a Maintenance Schedule for required servicing and step-by-step instructions for specific maintenance tasks. You'll also find important safety precautions, information on oils, and tips for keeping your Honda looking good.

An ICM (Ignition Control Module) system is used on this motorcycle; consequently, routine ignition timing adjustment is unnecessary. If you want to check the ignition timing, refer to the Honda Service Manual (page 148).

An optional tool kit may be available. Check with your dealer's parts department.

Before You Service Your Honda

- The Importance of Maintenance 18
- Maintenance Safety 19
 - Important Safety Precautions 19
- Maintenance Schedule 20
- General Competition Maintenance 22
- Before & After Competition Maintenance 26
 - Between Motos & Practice Maintenance..... 26
 - After Competition Maintenance 26

Service Preparations

- Maintenance Component Locations 28
- Seat 29
- Fuel Tank 30
- Subframe 32

Service Procedures

Fluids & Filters

- Fuel System..... 34
- Engine Oil 36
- Transmission Oil..... 39
- Coolant 41
- Air Cleaner 43
- Crankcase Breather 45

Engine

- Throttle 46
- Engine Idle Speed 48
- Clutch System 49
- Hot Start Lever..... 51
- Spark Plug 52
- Valve Clearance 53
- Piston/Piston Rings/Piston Pin..... 62

Chassis

- Suspension 70
 - Front Suspension Inspection 70
 - Rear Suspension Inspection..... 71
 - Recommended Fork Oil 72
 - Fork Oil Change 72
- Brakes 75
- Wheels 79
- Tires & Tubes 80
- Drive Chain 82
- Exhaust Pipe/Muffler..... 85
- Additional Maintenance Procedures..... 88

- Appearance Care 90