

## Periodic Checks

You should also perform other periodic maintenance checks at least once a month regardless of how often you ride, or more often if you ride frequently.

Also, check the odometer reading against the Maintenance Schedule and perform all maintenance that is due. ➔ [P. 33](#)

Tires and wheels	Check the air pressure (➔ <a href="#">P. 44</a> ), examine tread for wear and damage (➔ <a href="#">P. 44</a> ), and check the wheels for damage.
Fluid levels	Check the engine oil level (➔ <a href="#">P. 53</a> ), engine coolant level (➔ <a href="#">P. 57</a> ), and brake fluid level (➔ <a href="#">P. 59</a> ), final drive oil level (➔ <a href="#">P. 69</a> ).
Lights	Check that the headlight, brake light, taillight, turn signals and license plate light are working properly.
Controls	Check the freeplay of the clutch lever (➔ <a href="#">P. 65</a> ), throttle grip (➔ <a href="#">P. 73</a> ), and rear brake pedal (➔ <a href="#">P. 61</a> ).
Fuses	Check that you have a full supply of spare fuses.
Nuts & bolts	Check the major nuts and bolts, and tighten as needed.